

Cold Weather Hood System

How to fit

Universal Fleece Liner to all helmets including Centurion Reflex helmet:



Step 1:

Firstly, separate the top of the liner from the bottom/sides by releasing the velcro tabs.



Step2:

Then while holding the top section, ensuring that the Centurion logo is facing outwards and at the back of the helmet, insert the top section into the helmet, between the back two cradle straps and the shell. With the top section under the three cradle straps, position the bottom/sides so that it sits around the outside of the headband.



Step 3:

Finally, attach the four velcro tabs that are on each side of the central cradle strap (two each side of the helmet), so that the top and bottom parts of the liner are attached together. The liner can be tucked behind the four headband retainer tabs for neatness, whilst allowing the headband to be adjusted.



Step 4:

If Frost Cape required, zip the Cape to the Liner.

An alternative method of fitting the Fleece Liner to helmets excluding Reflex:



Step 1:

Firstly remove the Cradle Headband Assembly. To do this, carefully push the six White kit brackets (held at the end of the webbing) out of the helmet shell.



Step3:

Once the six kit brackets have been inserted through the six spaces in the Fleece Liner, the whole assembly needs to be reinserted into the helmet shell. Position the kit brackets above the correct holes in the helmet shell and then carefully push the kit brackets into the holes until firmly in place.



Step2:

Then feed the kit brackets carefully through the six spaces between the velcro tabs in the Fleece Liner. Ensure that the two kit brackets at the front of the headband go through the two holes at the front of the Fleece Liner (where there is no zip) and that the two kit brackets at the rear (by the headband strap) go through the two rear holes of the Fleece Liner (the deepest part of the Fleece Liner).



Step 4:

If Frost Cape required, zip the Cape to the Liner.